

Evoluent Programmable functions for each button:

1. Disabled
2. Left Click
3. Right Click
4. Wheel/Middle Click
5. Alt
6. Auto Pan
7. Back
8. Backspace
9. Close
10. Copy
11. Ctrl
12. Cut
13. Delete
14. Double Click
15. Enter
16. Esc
17. Explorer
18. F1
19. F2
20. F3
21. F4
22. F5
23. F6
24. F7
25. F8
26. F9
27. F10
28. F11
29. F12
30. Forward
31. Keystroke Recording
32. Launch Application
33. Maximize
34. Minimize
35. Page Down
36. Page Up
37. Paste
38. Pointer Speed Toggle
39. Print Screen

- 40. Run
- 41. Shift
- 42. Show/Hide Desktop
- 43. Spacebar
- 44. Start
- 45. Switch Applications
- 46. Tab
- 47. Undo
- 48. Zoom